

SO-PRG-B

MIFARE® CARD PROGRAMMER

The **SO-PRG** programmer is used to program MIFARE® cards – IDs and **MC-SRV-8** service cards (**CR Soft** program required). It can also be used to read the numbers of programmed cards and write them to another program (the HID keypad mode).

- MIFARE cards supported:
 - Ultralight CSN/SSN
 - Classic CSN/SSN/MSN
 - DESFire (EV1 / EV2 / EV3) CSN/MSN
- programming of **MC-SRV-8** service cards
- USB port (Micro-B)
- powered from the computer USB port
- LED indicators
- desk-top enclosure

TECHNICAL DATA

| | |
|--|---------------------|
| Operating frequency | 13,553...13,567 MHz |
| Operating temperature range | -10...+55° C |
| Standby mode current consumption | 45 mA |
| Max. current consumption | 74 mA |
| Weight | 65 g |
| Maximum humidity | 93±3% |
| Dimensions | 45 x 21 x 129 mm |
| Power supply voltage (from the USB port) | 5 V DC |